



## **SUPER MASTER OPERATIONS**

### **MODELS LCLX, LCMX, TLCL, TLCM**









The following instructions cover **Super Master Operations for LC Series** locks. The Super Master Combination is a six-digit combination used to reset the lock to the factory default combination (**502550**) in the event the user combination(s) are lost.

### **Set Super Master Combination**

**WARNING: Super Master Control will be permanently lost if you do not change the default Super Master Combination prior to changing any User combinations.**

**Caution: Once the Super Master Combination is set, it can never be changed.**

***Record the combination and store it in a secure place.***

1. Press #. Press 0.  
One green flash  displays with a beep .
2. Enter the **factory default Super Master Combination** of “120943”.  
One green flash  displays with a beep .
3. Enter the new six-digit Super Master Combination.  
One green flash  displays with a beep .
4. Enter the new Super Master combination again for verification.  
One green/red flash with a beep   indicates operation complete.

## Detect If Super Master Combination is Active

1. Press #. Press 9.


**If the Super Master User combination has not been disabled (i.e., no User combination has been changed) and has not been activated,**

two red flashes   display.

**If the Super Master combination is active,**

five red flashes      display.

**If the Super Master combination has been permanently disabled,**

a green flash  displays.



One green/red flash with a beep    indicates operation complete.

## Reset Lock Using Super Master Combination

1. Press #. Press 0.

One green flash  displays with a beep .

2. Enter the Super Master combination.

One green flash  displays with a beep  to indicate that the lock is ready to open.

3. Immediately rotate the container handle to unlock.

**Note: *The lock is now set to the factory default: Single Mode with an opening combination of "502550".***